

Edgecard Tooling

Series	Connector Seating		Single Insertion	Single Knock-Out	Broken Pin Knock-Out	Housing Removal		Replacement Blades
	Long*	Short**				Long	Short	
NKA	107-42223	107-42222	107-42188	107-42031	107-42120	107-42123	107-42292	107-42110
NJA	107-42396	107-42395	107-42188	107-42031	107-42120	107-42123	107-42292	107-42110
MK/NK C	107-42457	107-42456	107-42177	107-42031	107-43308	107-10931	107-42091	107-42110
MJ/NJ C	107-42109	107-42108	107-42177	107-42031	107-43308	107-10931	107-42091	107-42110
MK/NK D	107-10727	107-10766	107-42140	107-42031	107-42004	107-10781	107-42091	107-0190-13
MJ/NJ D	107-42134	107-42133	107-42140	107-42031	107-42004	107-10782	107-42091	107-42130
MK/NK E	107-42248	107-43092	107-42148	107-42031	107-25882	107-10931	107-42091	107-42147
MJ/NJ E	107-42146	107-42145	107-42148	107-42031	107-25882	107-10931	107-42091	107-42147
MF 36	107-10833	N/A	107-42633	107-42031	107-42047	107-10832	N/A	107-42116
MF 18	107-42085	N/A	107-42633	107-42031	107-42047	107-42070	N/A	107-42116
HE D	107-42502	107-42501	107-42140	107-42031	107-42004	107-10931	107-42091	107-42130
HE C	107-42460	107-42459	107-42177	107-42031	107-42002	107-10931	107-42091	107-42110
276	107-10722	107-42691	107-42554	107-42031	107-42047	107-10716	N/A	107-42100
.360 Wide	107-43275	107-43267	107-43331	107-42031	107-42002	107-43270	107-43269	107-43273

* Long tool A, C, and D grid expandable up to 66 dual positions.

* Long tool for E grid expandable up to 44 dual positions.

** Short tool A, C, and D grid expandable up to 33 dual positions.

** Short tool for E grid expandable up to 22 dual positions.

107-43267 (Up to 40 positions)

107-43275 (up to 61 positions)

276-Series (short - up to 30) (long - up to 50)

Header Tooling - 78 & 79 Series

No. of Postions	Connector Seating	Single Insertion	Single Knockout	Housing Removal	Broken Pin Knock-Out
10	107-10864	ALL TAILS 107-42698	107-42098	107-42379	N/A
14	107-42127			107-42379	
16	107-42005			107-42379	
20	107-42006			107-42623	
26	107-42007			107-42623	
30	107-43388			107-42623	
34	107-42008			107-42648-1	
40	107-42009			107-42648-1	
50	107-42010			107-43284-1	
60	107-42011			107-43284-1	
64	107-42128	107-43284-1			

NOTE: All single insertion, knock-out, and broken pin repair tooling are to be used in conjunction with impact handle P/N 107-42055

Series 89/189 Tooling

No. of Postions	Connector Seating	Housing Removal	Single Insertion	Single Knock-Out
9 Sock	107-10894	107-10895	107-42064	107-42390
15 Sock	107-42021			
25 Sock	107-42022			
37 Sock	107-42023	107-10883		
50 Sock	TBA	TBA	TBA	TBA
9 Pin	107-10882	107-10895	107-42063	107-42390
15 Pin	107-42024			
25 Pin	107-42025			
37 Pin	107-42026	107-10883		
50 Pin	TBA	TBA	TBA	TBA

Series 84/184 & 88/188 Tooling

No. of Postions	Connector Seating	Single Insertion	Single Knock-Out		Housing Removal	
			Series 84/184	Series 88/188	Series 84/88	Series 184/188
14 Recept.	107-43604-01	107-42036	107-42450	107-42244	107-25875	107-43065
24 Recept.	107-43604-02					
36 Recept.	107-43604-03					
50 Recept.	Dust Cover Insertion				107-25876	107-43066
14 Plug	107-25871	107-42035			107-25875	107-43065
24 Plug	107-25872					
36 Plug	107-25873				107-25876	107-43066
50 Plug	Dust Cover Insertion					

*To insert connector with the dust cover removed.

Series FM/FC/FA/FP Tooling

Series	Gang (Short) Seating	Gang (Medium) Removal	Gang (Long) Insertion	Single Insertion	Single Knock-Out	Broken Pin Knock-Out
FMT	Up to 16 positions 107-42080	107-42078(32)	107-42076(50)	107-10795	107-42031	Consult Factory
FMO	107-42629(16)	107-42630(32)	107-42631(50)	Consult Factory		
FMF	107-42629(16)	107-42630(32)	107-42631(50)	107-42632		
FCT	107-42293(17)	107-42294(33)	107-42295(51)**	107-42297		
FCF	107-42602(16)	107-42603(32)	107-42604(40)	107-42632		
FAT	107-42056(16)	107-42057(32)	107-42058(50)	107-10795		
FAO	107-42056(16)	107-42057(32)	107-42058(50)	107-10795		
FPT	N/A	107-42607	N/A	N/A		
WB	107-43070(23)	N/A	107-43072(61)	107-42051		

**For loading combs up to 16, 32, and 50 positions.

Note:

All single insertion, knock-out, and broken pin removal repair tooling are to be used in conjunction with impact handle part number 107-42055.

Series 121

(Coax Terminals)

Connector Cat. No.	Insertion Tool	Removal Tool
121-10302-2	107-42181	107-10835
121-10349-2	107-42018	107-42015
121-14165-2		
121-23979-2	107-42181	107-10835
121-13305-1	107-43184	107-43186/ 107-43185

Series 121

(2 Pos. Jumper)

Connector Cat. No.	Insertion Tool	Removal Tool
121-23999-25	107-42540	107-42544

Series 132 Tooling

No. Pos.	Connector Seating	Housing Removal	Single Insertion	Single Knock-Out
9	107-42626	107-42627	107-42532	107-42533
26	107-42531	107-42534		
30	107-43411-001	N/A		
52	107-43386	107-43387		

Series 130 Tooling

No. Pos.	Connector Seating	Housing Removal	Single Insertion	Single Knock-Out
5	107-43000	N/A	107-42675	107-42120
10	107-43005			
15	107-43010			
20	107-43015			
25	107-43020			
30	107-43025			
35	107-43030			
40	107-43035			
45	107-43040			
50	107-43045			

Series 121

(Power Terminals)

Connector Cat. No.	Insertion Tool	Removal Tool
121-27295-1	107-42677	107-42678
121-27295-2		107-42503
121-27296-1		107-42678
121-27296-2		107-42503
121-14204*	107-42486	
121-14205*		107-42229
121-14207	107-42489	
121-14208*	N/A	
121-24539	107-43839	107-42504
121-27239*	107-42252	
121-27240	107-42252	
121-27241	107-42181	107-10835
121-27242	107-42252	
121-27390	107-43429	
121-24564	107-42486	
121-24565	107-42486	

* Hand Held Impact Tool With Dracon Style Seating Available:

107-42488 for 121-14204 and 14205 (used in conjunction with impact handle 107-42055 purchased separately)

107-42228 for 121-14208 - 107-42253 for 121-27239 (used in conjunction with impact handle 107-42055 purchased separately)

NOTE: All single insertion, knock-out, and broken pin repair tooling are to be used in conjunction with impact handle P/N 107-42055